

savvy overview

..... savvyPanel System
 - - - - Action

Directory

Discover devices when **savvy** launches or by using the Directory menu.
 Discover by; Group, **savvyPanel** System, Discovery file, remote IP address, or all local devices automatically.

Device Name

Extruders Management A1 Extruder Polymer Co-Extrude
 Upper Rewind Fast Unwind Air and Water

Navigate Up Arrow

Touch or Click

Function Block Engine

With standard **savvy**, the Device Overview screen gives access to Comms Server setup, Function Block Engine, and native device functions where applicable.
 With **savvy-SFD** place function blocks graphically. Use function block list to review and arrange execution order.

Standard **savvy** **savvy-SFD**

Extruders Management Overview
 Comms Server Function Block Engine

SFD Note may be set up as a **savvyPanel** link

Operator Link

Touch Device Tile to view the SFD

Function Block

View functional elements and signal paths in relation to parameters.
 Parameters box adornments show type, any **drive.web** connections, read-only, **savvyPanel** tile present, re-scaling, and not-at-default.

Touch or Click a Function Block

Right-click on parameter, "Copy Parameter"

Right-click on parameter "Add to Parameter Dock"

Parameter Dock

Add parameters of interest to set, view, create trend graphs, and export .csv files for spreadsheets.
 Save Docks and open multiple Docks in different viewer windows.

Dock menu > Show Trend

Start Zoom Marquee
 Paste Parameter
 Show Trend Point Info

savvyPanel overview

Extruders West Unwind / Rewind

savvyPanel Systems

savvyPanel Password is not set in **savvyPanel** operator station. No **savvyPanel** data is shown.

Touch or Click

Systems Page

View all available **savvyPanel** Systems.
 Assign a **savvyPanel** System in each device's contextual menu, one per device.
 If a **savvyPanel** Password is set in the device, it must also be added in **savvyPanel** operator station software.

Systems Button.
 Requires Home Password if set.

Home Page

The first page in a **savvyPanel** System.
 Similar to Operator Pages except that it may be accessed by pressing the Home button from any Operator Page.
 Touch page-link tiles to go to Operator Pages.

Home Button.
 Requires Home Password if set.

Touch or Click Page-Link

Touch or Click

System OK Speed Setpoint Home

Right-click in an empty grid location and, "Paste Parameter".
 Choose desired graphic.

Melt Temp. 112.59 °C

Web Management